Bunk Jack Part #: 10573

Instructions

Compliant with all applicable OSHA 1910 and 1926 regulations.

Custom configurations not available. Not repairable. Contact customer service for details.

(2) Bunk Jacks required to receive up to 66 sheets of ½" CDX plywood. (1) HitchClip™ required per (1) Bunk Jack.

Bunk Jacks are specially designed to be utilized during construction to accommodate a full bunk of plywood, or to create a rooftop workstation, and can be adjusted to fit a 6/12-12/12 pitch..

Maximum weight per pair of Bunk Jacks: 4,000 lbs. (including all workers, tools, and equipment).

Installation and Use:

- 1. Install all necessary HitchClipsTM according to manufacturer's instructions. When used with Bunk Jacks, recommended spacing between HitchClipsTM is 6'.
- 2. Insert Bunk Jack Headpin into HitchClip™ key hole attachment point from top to bottom, and ensure Bunk Jack fully locks into place. HitchClip™ and Bunk Jack must be perpendicular to leading edge of fall hazard.
- 3. Adjust Bunk Jack so that platform staging will lie flat when installed. Secure and lock Bunk Jack with provided Locking Pin.
- 4. Place plywood across Bunk Jacks.

Materials: aluminum.

UPC-A Code: 672421105734











