

Eave Mounted Guardrail

Part #: 10586

Instructions

Compliant with all applicable OSHA 1910 and 1926 Subpart M regulations.

Minimum (2) Eave Mounted Guardrails required to set up complete system.

Compatible roof pitch: 0/12-12/12.



WARNING

Until fully protected from all fall hazards by Eave Mounted Guardrail system or other fall prevention system, ALWAYS use a complete and compatible personal fall arrest system, as determined by a Competent Person. NEVER make connections to Eave Mounted Guardrail.

Installation:

1. Clamp all bases of Eave Mounted Guardrail to open soffit rafters, then secure bases using (10) 1--5/8" #7 decking screws per base. NEVER attempt to support weight of base using only clamp. Maximum spacing between Eave Mounted Guardrails is 8'.

2. Adjust all posts until vertical. Secure all posts with provided locking pins.

3. Adjust toeboard installation location so toeboard will rest against work surface. Install all toeboards by securing to installation location on Eave Mounted Guardrail. Toeboards must be 2" x 4" construction grade lumber or better. Secure toeboards at each end with 1--5/8" #7 screw.

4. Install all guardrails. Guardrails must be 2" x 4" construction grade lumber or better. Guardrails must overlap a minimum 12" at each end. Adjust post rungs as needed to allow for guardrail lapping.

Materials: aluminum.

UPC-A Code: 672421105864

